



Tecties Reveal Support Plate offers an essential foundation for window reveals during construction. Its long leg is designed to fit securely into the bed joint of the outer leaf with an arrow pointing towards the reveal to ensure its stability. Reveal plates are only required at the base of reveals - there is no need to install additional plates in the upper courses of brickwork.

Installation

- Build up brickwork to the reveal level.
- Build the long leg of the reveal plate in to the external masonry leaf with the arrow pointing inwards towards the building. Ensure bricks are placed on the outer leaf before building any of the reveal brickwork.
- To guarantee optimal performance at least one course of bricks should be laid above the plate - providing a solid bearing and helping you achieve that perfect finish!

Code	Size	Material
TTRP	250 x 184mm	Grade 304 Stainless Steel
TTRP327	327 x 215mm	Grade 304 Stainless Steel

* Other sizes available on request.



Check that you are using the most up to date version of this product information, **scan the QR code.**

